

LEAKATOR® 10

Combustible Gas Leak Detector

Leak Detection



Actual Size is 8.5 inches
with 20" flexible probe

**easy-to-use****reliable****detects**

- Acetone
- Acetylene
- Benzene
- Butane
- Ethanol
- Ethylene Oxide*
- Gasoline
- Hexane
- Hydrogen
- Industrial Solvents
- Methane
- Paint Thinners
- Propane
- Natural Gas
- Naptha

Bacharach Makes Leak Detection Easy

Bacharach's Leakator 10 is a low maintenance combustible gas leak detection unit, small enough to be operated with just one hand, yet loaded with the kind of advanced features and technology professionals demand.

Powered for up to 30 hours of continuous operation by alkaline C-cell batteries, Leakator 10 comes complete with a flexible 20-inch long probe for hard-to-reach areas and a solid state sensor that will last for up to five years. Leakator 10 allows you to pinpoint large and small leaks quickly, while checking a relatively large area in a short amount of time.

*Only available by ordering P/N 19-7063



Features & Benefits

- **Visual Indicator**
10 Ultra-bright LEDs
- **Audible Indicator**
Loud audible ticking rate
- **30 Hour Battery Life**
Easily replaced C-cells
- **Sensitivity Thumb-Wheel**
Aids pinpointing leak detection
- **Operational Status LEDs**
English and international systems
- **Solid State Sensor**
Plug-in sensor, five year typical life
- **20 Inch Flexible Probe**
For hard to reach locations
- **Tough ABS Plastic Housing**
Durable and rugged
- **Carrying Strap**
Easy to use
- **UL Listed**
Intrinsically safe
- **CE Mark**
Electronic performance standard



SPECIFICATIONS

| | |
|---------------------|--|
| Housing | Molded, three piece ABS plastic in bright yellow color, includes carrying strap |
| Power | Five alkaline C-cells, not provided 30 hours typical life for continuous operation |
| Warm-up Time | Automatic, self check, about ten seconds to operational condition |
| Sensor | Semiconductor type. Five year typical life. Plug-in replacement |
| Probe | Self storing 20 inch flexible probe. Accommodates integral sensor |
| Sensitivity | 20 ppm useable sensitivity (methane) |
| Status indicators | Visual: 10 ultra-bright red LED's. Audible: Variable speed ticking sound. Earphone available for use in noisy environments. Power-On ultra-bright green LED, Fail ultra-bright yellow LED. Low Battery ultra-bright yellow LED |
| Environments | 23° to 130°F (-5° to 54°C), 10% to 90% relative humidity, non-condensing |
| Dimensions / Weight | Leakator: 18 oz. (0.51Kg.), 8.5" x 2.25" x 1.75" (21.6 cm x 5.7 cm x 4.4 cm) Case: Black HDPE, 17 oz. (.48Kg), 10.5" x 7" x 3" (26.7 cm x 17.8 cm x 7.6 cm) |
| Safety Approvals | UL listed, intrinsically safe, for use in Class I, Division 1, Groups A, B, C, and D classified areas |
| Warranty | One year limited warranty. See warranty card for more information |

ORDERING INFORMATION

| PART NO. | DESCRIPTION |
|----------|--|
| 19-7051 | LEAKATOR 10, in custom carrying case, UL Listed, flexible 20 inch probe for combustible gases and vapors, with instruction manual (batteries not included) |
| 19-7063 | Leakator ETO - For detection of Ethylene Oxide |
| 19-0398 | Replacement sensor and matching resistor |
| 19-0397 | Replacement rigid carrying case |
| 19-3091 | Replacement flexible probe assembly |
| 51-2529 | Optional Earphone |

Distributed By:



Leakator and Bacharach are registered trademarks of Bacharach Inc.
©August, 2002, Bacharach, Inc., all rights reserved. All information herein is subject to verification.
Product Bulletin-4098 08/02 10M DXC
Printed in U.S.A.



ISO 9001

